

BAND-IT[®]

Made in the
USA 

How To Apply BAND-IT[®] Edging

- 1. Prepare Surface Edge:** Fill any large holes • Sand rough spots • Remove sawdust • Cut Veneer 1/2" longer than surface to be covered
- 2. Apply Edging:** Preheat iron on "cotton" setting • Position edging • Slowly press iron over length of veneer • Check to see if glue is melting • *NOTE: Use Kraft paper or aluminum foil to protect iron bottom*
- 3. Bonding:** While still hot, press veneer down firmly with wood block or roller
Mistake? Simply reheat and reapply
- 4. Trim Edge:** Allow veneer to cool completely • Trim any excess with a BAND-IT[®] Edge Trimmer, razor blade or file • Sand smooth and finish as desired

